



LCD SCREEN WALL MOUNT WITH TILT

PARTS LIST

PART NUMBER	PART NAME	QUANTITY
1	WALL PLATE	1
2	INTERFACE PLATE	1
3	M8 x 12mm SECURITY ALLEN SCREW	4
4	M4 x 10mm ALLEN SCREW	6
5	M4 x 15mm ALLEN SCREW	6
6	M5 x 16mm ALLEN SCREW	4
7	M5 x 25mm ALLEN SCREW	4
8	M6 x 15mm ALLEN SCREW	4
9	M6 x 25mm ALLEN SCREW	4
10	Ø6.5mm Ø14mm x 9.5mm SPACER	4
11	M8 x 50mm COACH SCREW	6
12	#10 WALL PLUG	6
13	Ø8.3mm Ø19mm T1.6mm WASHER	10
14	2.5mm ALLEN KEY	1
15	3mm ALLEN KEY	1
16	4mm ALLEN KEY	1
17	5mm SECURITY ALLEN KEY	1



BT7533 is compatible with B-Tech Accessory collars.
Non-Vesa adaptor kit also available from B-Tech.
Please visit website for more details:
www.btechavmounts.com

LCD SCREEN WALL MOUNT WITH TILT

BT7533
v. 011BX 1007

Registered Design
No: 4003130

RECOMMENDED FOR SCREEN SIZES UP TO 42"

• 15° Tilt (down)

- Designed for LCD screens with a weight up to 40Kg (88lbs)
- VESA® mounting patterns: 200mm x 200mm, 200mm x 100mm, 100mm x 100mm & 75mm x 75mm

ASSEMBLY AND INSTALLATION GUIDE

THIS PACK CONTAINS: 1 WALL MOUNT & 1 MOUNTING HARDWARE KIT



10mm (3/8")
Drill bit required



Important Safety Instructions:

Do not install this product until the instructions and warnings have been read and understood thoroughly.

Please keep these instructions for future reference.

Due to the weight of LCD Screens and their fragile nature, B-Tech recommends that a professional installer is used when mounting this bracket. If you do not understand the instructions provided, or are not sure how to install this product, please contact a professional for advice and /or to install this mount. Failure to mount this bracket correctly may lead to serious injury and / or death. Please pay careful attention to where this mount is located. Some walls are not suitable for installation. If you install this mount on drywall it must be anchored into a wood stud, concrete block or brick behind the drywall. It is not suitable for securing to steel studs or weak concrete / brick. Installing on drywall alone will not support the weight of a flat panel screen. Ensure sufficient space and safety distance is allowed when installing this product. If installing in a public area, or over the likely path of pedestrians, this product should be mounted as far as possible from the public / pedestrians. When drilling holes it is particularly important to take care of electrical cables, water or gas pipes in the wall. It is important that all fixing screws included are not sufficient for the wall you are mounting this product on, please consult your local hardware store. The screen attached must weigh no more than the recommended weight of 40 Kg (88lbs). This mount must be mounted on a wall horizontally to prevent free motion due to the weight of the screen when adjusting the position. Ensure that when installing your screen on this mount, that the correct viewing distance and angles are observed, as well as avoiding any direct or reflected glare including glare from electric lighting etc. If there is any doubt, consult the instruction manual of your screen.

Proper attention should be paid when laying the connecting cables so that they do not cause a hazard.

It is recommended that periodic inspections are made of the mount to ensure that there is no change to the fixings or mount.

When cleaning the mount, use dry cloth only.

B-Tech International Limited, its distributors and dealers are not liable or responsible for damage or injury caused by improper installation, improper use or failure to observe these safety instructions. In such cases any guarantee will expire.

CAUTION: This wall mount is intended for use only with the maximum weights indicated. Use with heavier than the maximum weights indicated may result in instability causing possible injury

For more information on B-Tech Audio Video Mounts, please visit: www.btechavmounts.com




B-Tech International Limited
Long March, Daventry,
Northants, NN11 4NR, U.K.
info@b-tech-int.com

©COPYRIGHT 2007

B-Tech Audio Video Mounts
Sparks, NV. 89431, USA
Tel: 1 800 975 5812 • Fax: 1 800 592 2876
info@btechavmounts.com

BT7533 LCD SCREEN WALL MOUNT WITH TILT


1 Before Installation



Loosen the security Allen screws (**part 3**) and washers (**part 13**). Separate the wall plate (**part 1**) and interface plate (**part 2**) for later use.

2 Choose location for flat panel wall mount


Depending on the wall (e.g. concrete wall). It is necessary to drill suitable dowel/wall plug holes beforehand. Hold the wall plate (**part 1**) against the wall (with the label including directional arrow facing towards you and upwards) and mark through the desired position for where to drill the holes. Screw locations and quantities are for illustrative purposes only and not all wall fixing screws may have been shown. Distribute screws as evenly as possible to spread the load. Use the provided washers (**part 13**) with coach screws (**part 11**). The bracket should be mounted to a concrete/brick wall or stud wall. If you are unsure about mounting this product, please consult with a professional installer.



PLEASE PAY CAREFUL ATTENTION TO WHERE THIS MOUNT IS LOCATED. SOME WALLS ARE NOT SUITABLE FOR INSTALLATION. IF YOU INSTALL THIS WALL MOUNT ON DRYWALL IT MUST BE ANCHORED INTO A WOOD STUD, CONCRETE BLOCK OR BRICK BEHIND THE DRYWALL. INSTALLING ON DRYWALL ALONE WILL NOT SUPPORT THE WEIGHT OF A TELEVISION. WHEN DRILLING HOLES IT IS PARTICULARLY IMPORTANT TO TAKE CARE OF ELECTRICAL CABLES WATER OR GAS PIPES IN THE WALL. IT IS IMPORTANT THAT ALL FIXING SCREWS SUPPLIED ARE USED.

3 Attach interface plate to rear of screen


Depending on the VESA pattern on rear of LCD screen, fasten the VESA plate (**part 2**) to the screen by using M4, M5 or M6 Allen screws (**part 4-9**) are supplied. When using the M5 x 25mm Allen screws (**part 7**) or M6 x 25mm Allen screws (**part 9**) on screens with recessed fixings use the provided spacers (**part 10**).



IF UNSURE ABOUT THE MOUNTING PATTERN ON REAR OF SCREEN, PLEASE CONSULT THE SCREEN'S USER MANUAL.

BT7533 LCD SCREEN WALL MOUNT WITH TILT


4 Hang screen onto wall bracket (This procedure may require two people)



Carefully lower the screen so that the bottom slots in the interface plate (**part 2**) locate over the bottom pins in the wall plate (**part 1**). Ensure both the left and right slots have been located securely before releasing the weight of the screen. Once satisfied gently lower the weight of the screen and tilt forwards until the two top pins of the interface plate stop in the two notches on the wall plate. The screen is now sitting in a safe position allowing one person to easily adjust and fix the tilt.

THIS PROCEDURE MAY REQUIRE TWO PEOPLE.

5 Adjust and fix tilt



First locate 1 x security Allen screw (**Part 3**), fitted with a washer (**part 13**), in the bottom of the two curved slots where you see a threaded hole. Repeat this on the other side. Make sure to leave these screws loose enough so that you can still adjust the tilt. Next Decide upon the tilt angle you require. For 15 degrees tilt - Insert the remaining two security Allen screws with washers into the visible threaded hole in the top curved slot, repeat on the other side. For 7.5 degrees tilt - push the screen back into the vertical position and be sure to hold it there. Insert the remaining two security Allen screws with washers into the middle of the three threaded holes in the top curved slot, repeat on the other side. Release the screen weight. For vertical position - As above but insert the screws, with washers, into the holes nearest the wall. Release the screen weight. Once all 4 x screws are in position tighten them all fully using the Allen key provided (**Part 17**).